


ICS006 Water Flow Meter USER MANUAL

☒ EN ☐ DE




Email
service@rainpointus.com

Free Hotline
US: 1-833-381-5659 (EN)
EU: +44 800-808-5337 (EN DE)

Web
www.rainpointus.com

PRODUCT OVERVIEW




Specifications	
Waterproof	IPX6
Water Flow Rate	1~40 L/min (0.3~10.6 GPM)
Max Water Consumption	9,999.9 L or 9,999.9 Gal
Working Pressure	0.5 bar~8 bar (7.25~116 PSI)
Flow Max	10.6 GPM (2400L/H)
Measurement Tolerance	± 5 %
Water Temperature	41°F-104°F(5°C-40°C)
Suitable For	3/4 inch standard faucet / hose / sprinkler

1


QUICK INSTALLATION & PRECAUTIONS

Installing the Battery



Tips: How to remove the battery from the slot ?
Pinch the sides of the battery cover and clamp the battery out.

Installing Your Device




Precautions ⚠

1. Use the water flow meter in the **Out-of-Box Pre-Assembled** order to avoid water leakage.
 - The fitting ②, ③ and ④ are indivisible parts. Do not split them.
 - The fitting ① and ④, ② and ⑤ are different in the type of thread. Do not change the installation sequence of the fittings.
- Fitting ① is US standard thread , while the fitting ④ is EU standard thread. Fitting ⑤ is US standard thread with black color, while the fitting ② is EU standard thread with gray color.
2. **Follow the direction of water flow** to install the product to ensure accuracy.
3. If you have any questions, please feel free to contact us.
1-833-3815659 (US Office) | service@rainpointus.com

2

GET STARTED

4 Measurement Modes



→ Press the button briefly: the display switches to the next display mode.

(a) **FLOW MODE** — Display the real-time water flow in GAL/Min or L/Min.

(b) **CONSUMPTION MODE** — Measure the single water consumption. The display will reset after 30 sec without water flow or pressing the button.

(c) **AVG MODE** — Display the daily average water consumption for the last 7 days.

(d) **TOTAL MODE** — Measure the total water consumption up to the reset.

Special Functions:

- Energy-saving Standby :

Displayer auto shut-off (longer than 1 min without flow or without the pressing of a button)

- Switch GAL & L Unit :

→ Hold the button pressed for 2 sec in FLOW MODE to switch the format between gallon (GAL) and liter (L).

-Reset to Zero :

→ Hold the button pressed in CONSUMPTION/AVG/TOTAL MODE for 2 sec: The display data will be reset to 0.

-Low Battery Indicator :

→ Replace the battery when the low battery indicator appears on display.

3

TROUBLESHOOTING

Problem	Check If
Flow Mode doesn't show the real-time water flow during watering	• The display installed tightly into the flow meter body
Inaccurate Measurement	• The display installed correctly • The display installed tightly into the flow meter body • The water flow direction goes correctly • There is no leakage • The inner pipeline of water meter is full of water when using
Leakage	The accessories are in the correct position screwed with the correct thread
If your Rainpoint product does not operate properly after trying the troubleshooting steps, please contact us by phone or email : 1-833-3815659 service@rainpointus.com	

WARRANTY

Rainpoint provides a 1-year limited warranty on this product against manufacturing defects in materials and workmanship.

- 1) Warranty service can only be performed by our authorized service center. The original dated bill of sale must be presented upon request as proof of purchase to us, or our authorized service center.
- 2) To receive warranty service, the purchaser must contact with Rainpoint nominated service center for the problem determination and service procedure.

Thank you for your choice of Rainpoint products!

4

CUSTOMER SERVICE

If you find it difficult to set up and want to watch the setting tutorial video, please subscribe to our channel: Rainpoint on YouTube.

If the user manual don't have what you're looking for, and you need some helps, please prepare the LOT NO. of your device and contact us before returning the Rainpoint to the store.

LOT NO.: XXXXX (on the back of the meter)

US Free Hotline(English): +1 833-381-5659

(MON-FRI 9:30 AM-5:30 PM PST)

EU Free Hotline(English Deutsch): +44 800-808-5337

(MON-FRI 9:00 AM-5:00 PM CET)

Email: service@rainpointus.com

EC REP

NAME: VIAJE ELECTRONIC COMPANY LIMITED

ADDRESS: E588, 13 ADELAIDE ROAD, DUBLIN, D02 P950, IRELAND

Email: VIAJEELE@outlook.com

UK REP

NAME: SUJE ELECTRONIC COMPANY LIMITED

ADDRESS: S211 92a Bury Old Road, Manchester, England, M45 6TQ

Email: SUJEELECTRONIC@outlook.com

Manufacturer/Hersteller/Fabricant/Fabricant/Fabricante:

FUJIAN BALDR TECHNOLOGY CO.,LTD

ADDRESS/ADRESSE/ADRESSE/INDIRIZZO/DIRECCIÓN:

Floor 3, Building 2, No.71 Yangqi Road, Fuwan Industrial Area, Cangshan District, Fuzhou, China. 350008

Email: service@rainpointus.com



5