

PACKAGE CONTENTS

Please check all parts before installation.

	100FT	50FT	25FT
Quick Connector	x3	x2	x1
Pipe Clamp	x40	x20	x20
Three-way Socket	x30	x15	x7
Shower Head	x30	x15	x7
Ribbon	x40	x20	x20
End Plug	x4	x2	x2
Tube Cutter	x1	x1	x1
Thread Seal Tape	x1	x1	x1
Filter Screen	x3	x2	x1
Rubber washer	x3	x2	x2

SPECIFICATION

ITEM	SPECIFICATION
Material	PE+Metal+POM+Nylon+PP
Water Inlet	3/4" Faucet
Nozzle Type	Adjustable 360°
Outside Diameter (OD)	8 mm (0.31 in)
Inside Diameter (ID)	5.6 mm (0.22 in)

PRODUCT LIST

Quick Connector

Tube

Three-way Socket

Shower Head

End Plug

Pipe clamp

Ribbon

Tube cutter

Thread Seal Tape

Rubber washer

Installation Instructions

Step 1:
Use a tube cutter to cut the hose to the required length.

Step 2:
Insert the shower head into the three way socket.

Step 3:
Insert the tube into both ends of the three way socket.

Step 4:
Insert the end plug into the last three way socket of the system.

Installation Instructions

Step 5:
Secure the hose using a pipe clamp or ribbon

Step 6:
Connect to water source

Step 7:
Adjust direction as needed

Tip
Firmly insert the tube and shower head into the three-way socket to ensure that the tube and shower head are fully plug into the bottom of the three-way socket. Failure to insert them deep enough can cause leaks.

How to Use& Adjustment

Water Column Mode

Spray Mode


1. By rotating the nozzle head, You can switch between Water Column Mode and Spray Mode.

2. Fast Installation and Removal

Push Fit Connection
Simply insert the tube into the three way socket.
No heating or tools are required to achieve a secure and reliable connection.

Easy Release
Gently press the blue inner ring of the three-way socket and pull the tube out to quickly and easily disconnect the tube.

Tips & Notes

40-60 PSI

1. First-time use may require flushing the system.

2. Do not kink the hose.

3. Ensure all connections are firmly inserted.

4. Recommended water pressure range 40-60 PSI.

5.The quick connect comes with a built in filter pre installed.If leakage occurs at the connection between the quick connect and the faucet, an additional rubber washer may be added to ensure a proper seal.

Maintenance & Cleaning

1. Regularly clean the filter screen to prevent clogging and ensure smooth water flow.

2. Winter Freeze Protection: Before freezing weather arrives, turn off the main water supply and drain all water from the system to prevent damage caused by low temperatures.

3. If the system will not be used for an extended period, it is recommended to drain all water from the system and store it in a dry, frost-free environment.

Troubleshooting

Problems	No water flow from a single nozzle Uneven spray Leakage at the three-way connector Leakage at quick connect to faucet Leakage at the end plug The nozzle is damaged
Possible Causes	Different rotation angles of the nozzle Components not properly aligned or securely connected during installation Loose connection between the product and the water valve The end plug is not properly connected to the three way socket
Solutions	Replace it with a new nozzle. Rotate the nozzle to adjust the spray pattern and spray volume. Disassemble the components and reinstall them securely. Wrap PTFE (thread seal) tape around the faucet threads, add a rubber washer at the water inlet of the product, and then reconnect it to the faucet. Replace the end plug, or remove it and reconnect it properly

Safety Warnings

1. Water from garden hoses may contain contaminants that can cause serious health risks. Do not drink water from this system.

2. This product is not a toy. Keep out of reach of children.

3. Do not use this product for commercial purposes, hot water applications, or high-pressure systems. Misuse may result in personal injury or damage to the product.

4. Do not leave the system unattended during operation. Disconnect the water supply and store the product indoors during freezing conditions or extreme heat to prevent damage.

5. Do not direct water spray toward people, pets, or fragile objects. Improper use may cause personal injury or property damage.

WARRANTY POLICY

We provide a 5-year limited warranty period for the original purchaser/user, which starts from the date of original purchase. The warranty covers any defect in material or workmanship. During the warranty period, we will fulfill its warranty obligations by repairing or replacing the parts or the entire unit covered by the warranty free of charge according to the actual situation.

However, the warranty does not apply to problems caused by:
1. Normal wear and tear;
2. Failure to follow the accompanying operating instructions;
3. Products malfunction resulting from negligence, accident, improper use, maintenance or storage. Products that have been modified or repaired without authorization (including, but not limited to, modifications through the use of unauthorized parts or accessories)

CUSTOMER SERVICE

Our professional customer service team is committed to providing prompt and hassle-free support. If you encounter any issues with this product or during use, please do not hesitate to contact us. We will do our best to resolve the issue and provide a satisfactory solution, including replacement or refund when applicable.

To help us assist you more efficiently, please provide your order number and a brief description of the issue when contacting us.
US: +1 833-381-5659 (Mon-Fri: 9:30 AM - 5:30 PM PST)
DE: +49 800-182-0576 (Mon-Fri: 9:00 AM - 5:00 PM CET)
UK: +44 20-6628-3036 (Mon-Fri: 9:00 AM - 5:00 PM CET)
Email: service@rainpointonline.com

EC REP
NAME/NOM: VIAJE ELECTRONIC COMPANY LIMITED
ADDRESS/ADRESSE: E588, 13 ADELAIDE ROAD, DUBLIN, D02 P950, IRELAND
EMAIL/COURRIEL: VIAJEELE@outlook.com

UK REP
NAME/NOM: SUIE ELECTRONIC COMPANY LIMITED
ADDRESS/ADRESSE: 5211 Yixu Bury Old Road, Manchester, England, M45 6TQ
EMAIL/COURRIEL: SUIELECTRONIC@outlook.com

MANUFACTURER/HERSTELLER/FABRICANT/PRODUCTORE/FABRICANTE:
BALDR INTERNATIONAL LLC
16192 COASTAL HIGHWAY, LEWES, DE 19958

CE

Recycling symbol

RoHS symbol

WEEE symbol

EMBALLAGE À RECYCLER DANS LE BAC DE TRI

Made in China

RainPoint®
Pure Fun made easy

DRIP IRRIGATION SYSTEM
USER MANUAL

Model No.: JS-DIS101



For Garden, Lawn, Greenhouse & Plant Watering

US: +1 833-381-5659
DE: +49 800-182-0576
UK: +44 20-6628-3036
Email: service@rainpointonline.com