




Save the user manual for future reference. If you have any questions, please contact us to get support.

GARDEN HOSE
USER MANUAL

Model No.: XS58



US Hotline : +1 833-381-5659
DE Hotline : +49 800-182-0576
UK Hotline : +44 20-4628-3036

Email: service@rainpointonline.com
Website: www.rainpointonline.com

PRODUCT OVERVIEW


The garden hose is designed for various outdoor watering tasks including gardening, lawn care, and cleaning applications. This hose provides flexibility and resistance to UV rays, kinking, and abrasion, and will not harden even in winter.



Kink free and abrasion-resistance.



3/4" copper-plated aluminum connector



360°swivel handle.

SPECIFICATION

ITEM	SPECIFICATION
Internal Diameter	15mm
Outside Diameter	21mm
Optimal Working Water Pressure	150PSI
Working Temperature	-20°C-60°C (-4°F-140°F)

HOW TO USE



Step 1
Connect the water inlet of the hose to the faucet, timer or splitter;




Step 2
Uncoil the hose completely until it is laid out flat;



Step 3
Turn on the faucet to pressurize the hose and begin watering.



TIP:
To open the garden hose, place it upright on the ground and roll it with your hands to stretch it flat, reducing tangling.



To avoid tangles, please make sure to lay the hose completely flat before turning on the faucet.



NOTE:
Before installation, wrap Teflon tape around the faucet and add a rubber washer at the hose inlet to prevent leaks.



WARNING:



Sharp metals or stones may cause surface abrasions on the hose; avoid contact during use.



When not in use for an extended period during winter, please drain the water from the hose, clean it thoroughly, and store it indoors. Avoid direct sunlight, do not compress it, or place heavy objects on top. This will help extend its lifespan.



This product is not made from food-grade materials; do not use it for RVs or drinking water applications.

WARRANTY POLICY

We offer a 12-month limited warranty for the original purchaser, starting from the date of purchase. This warranty covers defects in materials or workmanship. During this period, we will repair or replace defective parts or units free of charge.

If you contact us to register the warranty, we'll extend the warranty to 5 YEARS free of charge. To activate and extend the warranty to 5 years, please contact us for warranty registration upon receipt of the package.

CUSTOMER SERVICE

Our customer service team guarantees hassle-free solutions within 24 hours on working days. If you encounter any issues with the product, please contact us for support. We're here to help and can offer replacements or refunds.



SUPPORT

Need Help?

Scan the QR code to get fast support
US Hotline : +1 833-381-5659
DE Hotline : +49 800-182-0576
UK Hotline : +44 20-4628-3036
Email: service@rainpointonline.com

EC REP
NAME: VIAJE ELECTRONIC COMPANY LIMITED
ADDRESS: E588,13 ADELAIDE ROAD,DUBLIN,D02 P950,IRELAND
Email: VIAJEELE@outlook.com

UK REP
NAME: SUJE ELECTRONIC COMPANY LIMITED
ADDRESS: S211 92a Bury Old Road, Manchester, England, M45 6TQ
EMAIL: SUJEELECTRONIC@outlook.com

BALDR INTERNATIONAL LLC
16192 COASTAL HIGHWAY, LEWES, DE 19958



Made in China

This paper box is recyclable and reusable