


USER MANUAL

2-Zone Wireless Water Timer with Gateway Set

Model: HTV210B+HWG023WBRF



Free Hotline

US: +1 833-381-5659 (EN)

DE: +49 800-182-0576 (EN, DE)

UK: +44 800-808-5337(EN)

Email: service@rainpointonline.com



Website: www.rainpointonline.com

CONTENT

1. INTRODUCTION	02
1.1 Contents in the Box	02
1.2 Product Overview	03
1.3 Specification	04
1.4 Product Features	04
2. INSTALLATION AND CONNECTION	04
2.1 Install App On Your Phone	05
2.2 Connection Steps	06
2.3 Connect the Timer to the Gateway	11
2.4 Timer Installation	15
2.5 Test Before Use	16
3. APP FEATURES AND FUNCTIONS	17
3.1 APP Home Screen	17
3.2 Device Home Page	18
3.3 Basic Setting	19
3.4 Plan Setting	21
3.5 Manual Watering	26
3.6 Rain Delay Setting	28
3.7 Event	29
3.8 Smart Scene	30
3.9 Weather Conditions	35
3.10 Plan Overview & Setting	36
3.11 Home Management	37
3.12 Google Assistant/Alexa Voice Control	38
4. RESET THE DEVICE	39
5. THE MEANING OF LED LIGHT	40
6. TROUBLESHOOTING	41
7. WARNINGS	43
8. WARRANTY	43
9. CUSTOMER SUPPORT	44




1.INTRODUCTION

1.1 Contents in the Box



- A. 1 x HTV210B 2-Zone Wireless Water Timer
- B. 1 x HWG023 gateway
- C. 1 x User Manual
- D. 1 x Quick Setup Guide
- E. 1 x Type C USB Cable

1.2 Product Overview



1.3 Specification

- 1" or 3/4" inlet thread and 3/4" outlet thread.
- Operating Water Pressure: 0.5-8 bar (7 - 116 PSI).
- Default Duration Time: 1 min - 12 hrs.
- Waterproof Level: IP54.
- Maximum 6 plans per zone.
- Working Temperature: 37.4°F - 122°F (3°C~50°C).
- Communicated by Bluetooth 5.0.
- Up to 100m depending on obstacles between gateway and timer.
- Powered by 4* AA batteries (not included).

1.4 Product Features

- Pairing with gateway for remote control.
- Review timer action events on the APP.
- Three watering mode: Normal Irrigation, Misting Irrigation, Cycle&Soak
- Up to six individual watering plans can be scheduled for each zone.
- Two outlets for different area watering needs.
- Can pair with gateway.

2. INSTALLATION AND CONNECTION



Setup Video



Customer Support

Tips: Please scan the QR code or search the link for setup video or customer support to install the device quickly.

Setup Video:

www.youtube.com/@rainpoint

Customer Support:

www.rainpointonline.com/pages/support

2.1 Install App On Your Phone

- 1) Download the RainPoint Home APP
Search for "**RainPoint Home APP**" on Google Play or App Store or scan the QR code to download the RainPoint Home APP.
- 2) Register your RainPoint Home APP account
Open your RainPoint Home APP, select **Register**. Follow the prompts to register a RainPoint Home APP account your email.


RainPoint Home 🔍



iOS




Android





2.2 Connection Steps

Follow the steps below to complete the device connection, ensuring that the gateway is close to the router during the connection process.

- a. Select the "+" icon in the top right corner of the app homepage to add a device, or you can tap the **"Add Device"** on the app homepage to add a device.



- b. Find and select **"HWG023"** or scan the QR code and then proceed to the next step.




- c. Enter the WiFi password and tap **"Next"**.

NOTE: Please make sure to connect to your **2.4GHz WiFi** for the device pairing.





- d. Follow the prompts on the page to complete the connection.
- ① Power the gateway using the Type C USB cable.
 - ② Press and hold the button until WiFi connecting indicator light on the device flashes blue rapidly, indicating that the device is in pairing mode.

Blue light
flashes rapidly



Press and
hold the button



- e. Please check the ☐ and tap **"Next"** to enter the application's pairing mode.




- f. Congratulations! The device has been successfully connected, and the gateway icon will display on the app homepage. You can tap the gateway icon on the app homepage to enter the gateway homepage for more settings of the device.




2.3 Connect the Timer to the Gateway

- 1) After successfully connecting to the gateway, tap the gateway icon on the app homepage to go to the gateway's homepage, tap **"Add Device"** and then tap **"Add New Devices"** to add the timer to the gateway's sub-device.




HTV210



- 2) Find **"HTV210B"** or the icon to add the water timer. Or press  to scan the QR code and enter into the next step.



- 3) Insert **4 new AA alkaline batteries (not included)** into the battery compartment of the timer. Restore the battery compartment and make certain it is secured.



⚠ WARNING:



- *Please use only alkaline batteries.
- *Do not mix old and new batteries.
- *Batteries are to be inserted with the correct polarity.
- *Exhausted batteries are to be removed from the product.
- *Please remove the battery from long-term no use.

- 4) Press and hold the button of the timer until **the light flashes red quickly**. Meanwhile, select "**Next**" on the APP and it will start searching the device automatically.



NOTE: The timer can be paired with gateway or Bluetooth. Use a 2.4GHz WiFi to connect the gateway and router, then pair the timer with the gateway via Bluetooth. Please make sure your phone's Bluetooth function is on for better pairing.


- 5) If you fail to connect the timer for the first time, you can hold the button on the timer(or refer to **RESET THE DEVICE** in the manual) to reset and reconnect it.
- 6) After successfully connecting and creating plans, the next watering plan time will be displayed on the device page.
- 7) After the connection is successful, the icon of the water timer and gateway will be displayed on the APP home screen.




NOTE: When you add the timer to the gateway, it becomes a remote control timer.

2.4 Timer Installation

- 1) Turn off the garden faucet.
- 2) Screw the timer to the garden faucet and make it as vertical as possible to the ground (as shown below) to prevent rainwater from accumulating and leaking into the interior.
- 3) Screw the garden hoses to the timer outlets.
- 4) Turn on the faucet after programming the timer.




Tips: If the connection between the timer and the faucet or hose is not tight or is leaking, wrap Teflon tape clockwise around the external threads (2-3 turns) to secure the connection.



Please install the filter correctly (as shown left) and keep it clean to achieve a better filtering effect.

Warning: Please make sure the gateway is near the Bluetooth water timer when connecting or setting the watering plan. The best range for connection and operation is within 100 meters in the open area. If there are walls, iron gates or bushes blocking, please shorten the distance between them to better receive the signal.

2.5 Test Before Use



Congratulations, you have completed the connection and installation of the Bluetooth Water Timer. Please test whether the internal valve of your water timer is normal before using it.

- 1) Keep the faucet turned off.
- 2) Press the left/right zone button of the timer, with a "click" sound, the left/right valve inside the timer opens for manual watering. After a few seconds, press the left/right zone button again, the "click" will sound again, and the left/right zone valve will close.
- 3) Turn on the faucet a little bit, press the left/right zone button of the timer to check if the water flows out or shuts off as expected. If yes, the valves are normal, please use it with confidence! If not, please repeat the above steps several times.

The test is over, everything is normal, please keep the faucet fully turned on!

Note: When testing, please keep away from the water outlets of the timer to avoid being splashed and wet.

The valves are usually activated, but external factors such as force or environmental conditions during storage and transportation may cause the valves to be protectively closed. In such cases, you need to activate the timer valves manually.

3. APP FEATURES AND FUNCTIONS

3.1 APP Home Screen

Home Management

You can locate your home, customize the home name and add family members or add other homes. It is convenient for you to manage irrigation schedules for different residences.

All Devices

A check list of all the devices you have connected. Tap the icons to enter the operation page of devices you have added to program the operation schedule of the device.

Smart

You can create various intelligent scenarios as needed to make your system smarter.

Plan

On the "Plan" screen, you can view, customize, and turn on or off the watering schedules for the water timer. You can also turn on or off the "Rain Delay" function for rainy days and choose its duration from 24, 48, or 72 hours.

Add Devices

You can add multiple RainPoint devices on the APP to create a smart home irrigation system.

Room Management

Room Management is for indoor automatic irrigation system in different room.

Event


On the "Event" screen, you will receive notifications for device online/of-fline status, irrigation records, high-temp alerts, and other information.

Me

On the "Me" screen, Get FAQs and user manuals, as well as report issues through "FAQS & Feed back". Connect the water timer to your Google Assistant or Amazon Alexa for voice control of the valve. Adjust language preferences and turn on/off notifications in the "Settings" menu.



3.2 Device Home Page



Setting

Tap the setting icon on the top right corner, you will enter the page for device setting and customize the device watering.

Left Side Valve

Choose to manage plans or manual watering for the left zone.

Right Side Valve

Choose to manage plans or manual watering for the right zone.

Next Plan Time

After setting your watering schedules, the device page will show the next plan time.

Manual:

Tap on "Manual", and you can choose three manual irrigation modes, namely Normal irrigation, Misting irrigation and Cycle&Soak. Set a temporary irrigation plan according to your specific needs

Event:

Tap on "Event", and you can view various operation records of the devices, such as watering records, devices status, manual records and so on.

Plan:

Tap "Plan" and you will enter the plan set page, up to 6 plans per zone are available. You can also set "Rain Delay" for rainy days by 24/48/72H. Seasonal Adjustment allows you to adjust your watering schedule by month with one click (10%-200%).


Tap the calendar icon to check your plan.

3.3 Basic Setting

Find the icon in the upper right corner of the APP's home page and enter the "Settings" page.


In the basic settings, you can view and manage the basic information of the device.

You can also configure default values for specific functions. Take ZONE 1 as an example, the setting method for ZONE 2 is the same as that for ZONE 1:
Smart Plan Recommendation: Set your "Zone Information" (Plant Type / Soil Type / Nozzle Type / Duration of light / Ground Slope), then tap the "Smart Plan Recommendation" button to activate the feature. This will provide corresponding watering suggestions in the "Plan Setting" section.







Misting Irrigation: You can set the watering duration and interval time for both Zone 1 and Zone 2 from 1 s -60 mins.

Default Duration Time: Set the default watering duration for manual irrigation mode.



3.4 Plan Setting

- 1) Select **Plan**  and start to create a new auto-watering plan.
Select the "+" button and then start creating a new automatic watering plan.




2) Set the watering mode and time

Tap the icon in the upper right corner of the Irrigation "Plan" page and choose the type of irrigation plan you want to set.

Normal Irrigation: Set the Start Time, Irrigation Duration, Repeat (water frequency) and Effective Date.





Misting Irrigation: Set the Repeat (water frequency), Irrigation Duration, Run Time, Interval, Start Time, Effective Date.

Cycle & Soak: Set the Repeat (water frequency), Irrigation Duration, Each Watering&Soaking After Watering, Start Time, and Effective Date.



3) Set the Repeat(watering frequency) of your plan.

There are five options namely Every day, Odd Dates, Even Dates, Intervals and Custom.



- 4) After completing the settings, tap the "✓" in the upper right corner to save your plan. You will see an overview of the plan displayed in the list. If you need to delete a plan, you need to click on the plan, enter the plan details page, and tap the "Delete" button to delete it.

Seasonal Adjustment:

The adjustment ratio ranges from 10% to 200% to meet the irrigation needs of different seasons.





Tip:

100% maintains original watering duration; values below shorten it, while values above extend it.

Plan Calendar:



tap Calendar  to check watering plan.





Used to view the schedules of all plans.

3.5 Manual Watering

Select the "Manual"  on the home page, manually open the temporary irrigation plan, and you can set the irrigation duration. Three manual irrigation mode: Normal irrigation, Misting irrigation and Cycle&Soak.






Note: When you turn on manual watering, if there is a plan running now or there will be a plan starting during your manual water time, the schedule will be skipped for this time.

3.6 Rain Delay Setting



Tap the **"Plan"**  button to access Rain Delay. This function pauses scheduled watering during periods of high soil moisture, such as rainy days. The timer automatically resumes with the next scheduled cycle after the delay period (24/48/72h).



3.7 Event

Tap on the **"Event"**  button, and you can select the operation records of the device that you want to view.


Tap "🔍" to quickly filter by selecting devices and types.



3.8 Smart Scene



The Smart Scene function allows you to set smart schedules for the devices execute automatically according to the set conditions such as device status, time and weather.

For example, RAINPOINT HOME APP can obtain weather forecast information of your home location. When you set the condition for immediately delaying the watering plan when it rains, the timer will automatically execute the watering delay when it rains in your local area. You don't need to worry about whether it is raining at home when you are traveling.





Steps to Set Smart Scene

- 1) **Create Scene**
Go to **"Smart"** page → Tap **"Create Smart Scene"** or **"+"** (top-right)
- 2) **If**
Add Condition: Device Status/Time/Weather
- 3) **Then**
Add task to execute when conditions are met: Control Device/Send Notification/Rain Delay
- 4) **Effective Period**
Set active time range and Effective Date
- 5) **Daily Frequency Limit**
Max executions per day
- 6) **Save Scene**
Tap **"Create"** → Name scene → Tap **"Confirm"**
Automations run as schedule.
Manage scenes in the **"Smart"** page.




How to set automatic rain delay?

- 1) Tap **"Smart"** at the bottom of the APP home screen.
- 2) Tap **"Create Smart Scene"** or the "+" icon on the top right corner to add an automation task.
- 3) Tap **"Add Condition"**, then select **"Weather"** ; locate the city, select **"Type Of Weather"** and then select **"Heavy rain"**; tap **"Confirm"** to continue.





Note: Please accurately locate the city where your home is located. The APP will automatically obtain weather forecast data based on the city you locate. When the weather forecast turns to heavy rain, the conditions for execution will be triggered.

- 4) Tap **"Add Task"**, select **"Control Device"** to set up a task about the device operation.
- 5) Select **"HTV210"**.
- 6) Tap **"All Plans Delayed"** of Zone 1 to set the delay days and tap **"Confirm"**; then tap the **"+"** icon on the right of **"Then"** to set the **"All Plans Delayed"** of Zone 2.



Note: For the task performed by the device, select **"Control Device"**.

- 7) Check your execution conditions and tasks.
- 8) Tap **"Create"** to save your settings.



For example: The picture on the right shows that when the weather in New York is heavy rain, the left and right valves of the HTV210B WiFi irrigation timer will be automatically closed, and watering will be delayed for one day

3.9 Weather Conditions

In the Home screen, you can check for the weather conditions.

First-time setup:

Tap **"Get Location"** → **"Save"** to store your location


Instantly see **24H** forecast:

- **Temperature & Humidity**
- **Rain forecast & Wind (Direction/Speed)**
- **7-day forecast**

Update Location:



Me - HOME Management - My Home - Location - Get Location - Save.

Adjust irrigation schedules based on forecast conditions to optimize water usage.



3.10 Plan Overview & Setting



In the **Plan** screen, you can check the plan you set of all your connected devices and adjust each plan here conveniently. You can also set the **Rain Delay** by 24/48/72H easily or turn off the **Rain Delay** button.



3.11 Home Management

Rainpoint supports adding family members and sharing your home device to achieve co-manage the home irrigation system with your family.



- 1) Tap **"Me"** at the bottom of the APP home screen.
- 2) Select **"HOME Management"**, you can set the current home or add home.
- 3) Set your **HOME Name, Room or Zone, Location, Time Zone, Members, Units Format**.



3.12 Google Assistant/Alexa Voice Control

How to get third-party control / voice control?

If you have a **Google Assistant** or **Amazon Alexa**, please tap "**Third-party Voice Service**" in "**Me**" page, and then tap "**Google Assistant**" or "**Amazon Alexa**" to check the operation guide to connect your water timer to the voice control device. After successfully connecting, you can control the water timer by voice.



4. RESET THE DEVICE

How to reset the water timer?

Step 1. Remove all batteries from the battery compartment.

Step 2. After 10 seconds, insert 4 fresh AA alkaline batteries into the compartment of the timer.

Step 3. After installing the battery, press and hold the button on the timer without releasing it until the LED indicator quickly flashes (2 times per second), indicating that the water timer is restored to pairing mode.

How to reset the Gateway?

Step 1. Disconnect power

Unplug Type-C USB cable → Wait 5 seconds

Step 2. Execute reset step

a. Reconnect Type-C USB power cable

b. Press and hold the button for 5 seconds until:

- The left blue LED indicator flashes rapidly (pairing mode)

5. THE MEANING OF LED LIGHT

LED indicator color of HTV210B Wireless water timer

- 1) Power-on reset: When powered on, the Blue and RED lights are on simultaneously for 1 second.
- 2) Factory reset - -Power-on self-test - Pairing state: RED light on for 2 seconds - RED and BLUE lights on simultaneously for 1 second - RED light flashes rapidly for pairing - BLUE light on for 2 seconds(indicating successful pairing).
- 3) Irrigation mode (Normal state): Blue light flashes once every 4 seconds, staying lit for 0.1 second each time.
- 4) Irrigation mode (Scheduled but unsynchronized time): Blue light flashes once every 4 seconds, staying lit for 0.1 second each time.
- 5) Interval mode: Blue light flashes twice every 4 seconds, staying lit for 0.1 second each time.
- 6) Low battery status: RED light flashes once every 3 seconds, staying lit for 0.1 second each time, indicating the battery is in a low voltage state.

LED indicator color of HWG023 gateway

- 1) Power on: Power indicator light is always on, WiFi connecting indicator light flashes once.
- 2) Smart network pairing: Power indicator light is always on, WiFi connecting indicator light blinks quickly.
- 3) Network pairing successful: Power indicator light is always on, WiFi connecting indicator light is always on.
- 4) Network pairing failed (timeout in pairing mode): Power indicator light is always on, WiFi connecting indicator light is off.
- 5) Gateway disconnection (disconnected after successful pairing): Power indicator light is always on, WiFi connecting light flashes slowly (attempting to connect to the network).

6. TROUBLESHOOTING

Issue	Possible Cause	Advice
Can't Turn On /off The Valve	1) Low battery. 2) Impurities in water inlet. 3) Unstable network or delayed response.	1) Replace fresh batteries . 2) Regularly clean the filter port of impurities to avoid disruptions in use. 3) Wait a while and try again.
Timer Won't Connect	1) Unstable WiFi network. 2) Long distance from the gateway and router.	1) Check that the WiFi network environment is working. 2) Ensure the water timer is close to the gateway and router while connecting. 3) Repair the timer: Press the button until the red light flashes rapidly. (Or remove the device and then reconnect again.)
Gateway Cannot Connect	1) Not using 2.4GHz WiFi. 2) Incorrect WiFi password. 3) Gateway not in pairing mode.	1) Confirm 2.4GHz WiFi connection. 2) Confirm that the WiFi password has been entered correctly. 3) Press and hold the button on the gateway without releasing it until the left blue LED indicator quickly flashes, indicating that the gateway is restored to pairing mode.

Issue	Possible Cause	Advice
Plan Not Executed On Time	1) There are impurities in the water inlet filter. 2) Rain delay function is on. 3) The conditions for automatically stopping the plan when it rains is set. 4) In a low-power state, the timer enters low-power protection mode and does not execute the schedule. 5) No irrigation time/period parameters are currently set.	1) Inlet impurities need to be cleared regularly so that they do not clog up and interfere with the irrigation programs. 2) Check if the rain delay function is on and turn it off. 3) Check if the conditions for automatically stopping the plan when it rains is set and delete the setting. 4) Replace the batteries with new ones. 5) Confirm that the irrigation time/period parameters are set.
Water Inlet Leakage	1) No filter or not be placed horizontally. 2) The faucet is not the right standard 3/4" size.	1) Add a filter and make sure it's placed horizontally in the inlet. 2) Make sure the faucet is a 3/4" faucet. 3) Strengthen it with teflon tape.
Low Water Pressure	1) Filter blockage. 2) Inlet pressure is not enough to support watering.	1) Check if the filter is clogged, if so, clean or replace the filter. 2) Make sure the timer is installed properly and not cross-threaded. 3) Installation of a booster pump or other auxiliary equipment to increase water pressure.

7. WARNINGS

- 1) For outdoor use with cold water only. Placing the timer in the sheltered outdoors will prolong its life.
- 2) To avoid damage, please tighten it without using tools.
- 3) The filter should be placed horizontally in the water inlet to prevent leakage.
- 4) When the power is low, please replace the batteries to avoid the interruption of normal operation; when replacing the batteries, please make sure that the battery compartment is dry.
- 5) When the timer compartment is not in use, please remove the batteries and store it indoors.
- 6) Don't use the timer under a temperature more than 122°F(50°C), or less than 37.4°F (3°C).
- 7) Don't subject the product to extreme force and shock.
- 8) Severe electrical shock could result if water is sprayed into outlets or sources of electrical current. Never immerse the product in water.
- 9) Do not mix old and new batteries or different types of batteries.
- 10) Please install the timer vertically to the ground to avoid valve body damage.
- 11) Under freezing temperatures, timers should be removed from the faucet and stored indoors to avoid potential freezing damage.
- 12) Please clean filters regularly and replace if it is worn in order to prolong working life of timer.

8.WARRANTY

RainPoint provides a 1-year warranty against manufacturing defects in materials and workmanship from the date of purchase. During the warranty period, we'll replace free of charge the product found to be defective under reasonable use and service as determined solely by RainPoint.

9. CUSTOMER SUPPORT

If you find it difficult to set up and want to watch the setting tutorial video, please subscribe to our channel RainPoint on YouTube.



Or scan the QR code to visit the RainPoint channel on YouTube quickly.

If the app and the user manual don't have what you're looking for, and you need some help about our product, please contact us before returning the product to the store and let us know the LOT NO. of your device.

LOT NO.: XXXXXX (on the back of the device)

US toll free (English): +1 833-381-5659

(Mon-Fri: 9:30 AM-5:30 PM PST)

DE toll free (Deutsch/English): +49 800-182-0576

(Mon-Fri: 9:00 AM-5:00 PM CET)

UK toll free(English): +44 800-808-5337

(Mon-Fri: 9:00 AM-5:00 PM CET)

Email: service@rainpointonline.com

FCC STATEMENT: (FCC ID: 2AWDBH115FRF+2AWDBH115FRF)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Warning: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

EC REP

NAME: VIAJE ELECTRONIC COMPANY LIMITED

ADDRESS: E588, 13 ADELAIDE ROAD, DUBLIN, D02 P950, IRELAND

Email: VIAJEELE@outlook.com

UK REP

NAME: SUJE ELECTRONIC COMPANY LIMITED

ADDRESS: S211 92a Bury Old Road, Manchester, England, M45 6TQ

Email: SUJEELECTRONIC@outlook.com

Manufacturer: FUJIAN BALDR TECHNOLOGY CO.,LTD

ADDRESS: Floor 3, Building 2, No.71 Yangqi Road, Fuwan Industrial Area
Cangshan District, Fuzhou, China. 350008

Email: service@rainpointonline.com



Made in China



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !



Not included





Scan the QR code to
get fast support

Need Help?

Please contact us

US toll free: +1 833-381-5659

(Mon-Fri: 9:30 AM-5:30 PM PST)

DE toll free: +49 800-182-0576

(Mon-Fri: 9:00 AM-5:00 PM CET)

UK toll free: +44 800-808-5337

(Mon-Fri: 9:00 AM-5:00 PM CET)

Email: service@rainpointonline.com

